



Tr1 S11 SWR 100.0m/ Ref 1.000 [F4]  
 Tr2 S22 SWR 100.0m/ Ref 1.000 [F4]  
 Tr3 S33 SWR 100.0m/ Ref 1.000 [F4]  
 Tr4 S44 SWR 100.0m/ Ref 1.000 [F4]



1 Start 3 GHz IFBW 1 kHz Stop 4 GHz Cor

AMPLITUDE BALANCE


Tr1 S31 Log Mag 200.0m/ Ref -3.200dB [F4]  
 Tr2 S41 Log Mag 200.0m/ Ref -3.200dB [F4]



2 Start 3 GHz IFBW 1 kHz Stop 4 GHz Cor

ISOLATION

Tr1 S21 Log Mag 10.00dB/ Ref 0.000dB [F4]



3 Start 3 GHz IFBW 1 kHz Stop 4 GHz Cor

System

Print

Abort Printing

Printer Setup

Invert Image

ON

Dump

Screen Image

E5091A Setup

Misc Setup

Backlight

ON

Firmware

Revision